Salbæk Technology Group
support@sal-tech.com
Skype: easy.packaging


Motor M5-1 (T6-1-61210) Installation Guide for Automatic Polypropylene Strapping Machine

© Copyright 2020 Salbæk Technology Group

General Information

This document is a guide for Motor (M5-1) Assembly. Listed below are the machines which are compatible to the T6-1-61210 Motor (M5-1) spare part:


- TP-601A
- TP-601AS
- TP-601B
- TP-601BS
- TP-601BP
- TP-601BPS



© Copyright 2020 Salbæk Technology Group

Spare Parts Assembly


T6-1-61210 Motor (M5-1) is a part for the Automatic Polypropylene Strapping Machine. The Motor (M5-1) is connected to the following spare parts:



22 – Motor (M5-1) Ass'y
11 – Motor (M5-1)
21 – Bracket Ass'y
14 – HBS, M6x30
12 – SW, M6
15 – HSS, M5x8
10 – Bracket
12 – SW, M6
56 – HN, M6
9 – Lever
50 – Metal Bush, 1504
20 – Collar
19 – Support Plate
49 – SW, M5
57 – THS, M5x40

T6-1-61210 Motor (M5-1) is installed and placed inside the Bracket Ass'y and Tension Arm Group (T6-1-61001). To install/replace the Motor (M5-1), start with taking out the body or casing of the machine. T6-1-61210 Motor (M5-1) should be gently slide inside the Bracket (T6-1-61200) and must be locked properly by fastening HBS, M6x30 using SW, M6 and HN, M6.

© Copyright 2020 Salbæk Technology Group




1 – Cam Group
2 – Slide Table Group
3 – Press Group
4 – Heater Group
5 – Strapping Head Group
6 – Tension Group
7 – Feed Group

[Disclaimer: It is not the responsibility of HBC/STEP for the service you perform and the choice and securing of skills needed by person doing the service.]

© Copyright 2020 Salbæk Technology Group

Images



[T6-1-61210 Motor (M5-1) Drawing]



[Actual Image]

© Copyright 2020 Salbæk Technology Group