Salbæk Technology Group
support@sal-tech.com
Skype: easy.packaging


Upper Feed Roller for 12mm (T6-1-71123) Installation Guide for Automatic Polypropylene Strapping Machine


© Copyright 2020 Salbæk Technology Group

General Information

This document is a guide for Upper Feed Roller (For 12mm) Assembly. Listed below are the machines which are compatible to the T6-1-71123 Upper Feed Roller (For 12mm) spare part:

- TP-601A
- TP-601AS
- TP-601B
- TP-601BS
- TP-601BP
- TP-601BPS
- TP-601D1






© Copyright 2020 Salbæk Technology Group

Spare Parts Assembly


T6-1-71123 Upper Feed Roller (For 12mm) is a part for the Automatic Polypropylene Strapping Machine. The Upper Feed Roller is connected to the following spare parts:



9 – Upper Feed Roller Set (For 12mm)
12 – Snap Ring, H-24
10 – Bearing, 628ZZ
2 – Upper Feed Roller (For 12mm)

T6-1-71123 Upper Feed Roller (For 12mm) is installed and placed in the Upper Feed Roller Ass'y and Feed Group (T6-1-70004). To install/replace the Upper Feed Roller, start with taking out the Snap Ring of the machine. T6-1-71123 Upper Feed Roller (For 12mm) should be gently slide off/to the Upper Feed Roller Shaft (T6-1-71130).

© Copyright 2020 Salbæk Technology Group




1 – Cam Group
2 – Slide Table Group
3 – Press Group
4 – Heater Group
5 – Strapping Head Group
6 – Tension Group
7 – Feed Group

[Disclaimer: It is not the responsibility of HBC/STEP for the service you perform and the choice and securing of skills needed by person doing the service.]

© Copyright 2020 Salbæk Technology Group

Images



[T6-1-71123 Upper Feed Roller for 12mm Drawing]



[Actual Image]

© Copyright 2020 Salbæk Technology Group