Salbæk Technology Group
support@sal-tech.com
Skype: easy.packaging


Return Spring (TA-071) Installation Guide for Semi-Automatic Polypropylene Strapping Machine

© Copyright 2020 Salbæk Technology Group

General Information

This document is a guide for Return Spring Assembly. Listed below are the machines which are compatible to the TA-071 Return Spring spare part:


- TP-201
- TP-202
- TP-203
- TP-202L
- TP-201CE
- TP-202CE
- TP-203CE
- TP-202LCE
- TP-201YS



© Copyright 2020 Salbæk Technology Group

Spare Parts Assembly

TA-071 Return Spring is part for the Semi- Automatic Polypropylene Strapping Machine. The Return Spring is connected to the following spare parts:



122 – Rear Bar Ass'y
74 – Rear Bar
73 – Spring Hook
71 – Return Spring
70 – Spring Pin, 3x18
69 – Press Bar
123 – Press Bar Ass'y
79 – Front Bar
77 – Spring Pin, 5x14
78- Spring
75 – Plunger
76 – Bearing, 635ZZ
124 – Front Bar Ass'y

The TA-071 Return Spring is installed inside the machine assembly. It is connected to the Spring Hook (TA-073) of thw Rear Bar (TA-074), Press Bar (TA-069/TA-069S) and Front Bar (TA-079/TA-079S). These parts can be found on the Main Body Block (T5-1-10110) of the machine.

[Disclaimer: It is not the responsibility of HBC/STEP for the service you perform and the choice and securing of skills needed by person doing the service.]

© Copyright 2020 Salbæk Technology Group

Images



[TA-071 Return Spring Drawing]



[Actual Image]