


Support (M7-5-101202) Installation Guide for Automatic Strapping Machine

General Information


This document is a guide for Support Assembly. Listed below are the machines which are compatible to the M7-5-101202 Support spare part:

- TP-702-59
- TP-702B
- TP-702BP





Spare Parts Assembly

M7-5-101202 Support is a part for the Body Frame Group of the Automatic Strapping Machine. The Support is connected to the following spare parts:




- 6 – Adjustment Leg
- 14 – Label
- 2 – Support**
- 24 – SW, M6
- 28 – PW, M6 (A)
- 17 – HBS, M6×16 (N)
- 25 – SW, M16
- 7 – Caster (Brake)
- 8 – Caster (Free)
- 34 – Grommet
- 11 – Foot Bar Ass'y

M7-5-101202 Support is installed and placed under the Body Frame with Frame Group (M7-5-100001/M7-5-100011/M7-5-100021). It is attached in between the Adjustment Leg (M7-5-101700) and Caster Brake (T7-5-10170) and Caster Free (T7-5-10180). The Foot Bar Ass'y (M7-5-110002/M7-5-110012/M7-5-110021) is also attached on the Support (M7-5-101202) using HBS, M6×16 (N) (HBS0616N), SW, M6 (SW06) and PW, M6 (A) (PW06A).



- 1 – Body Frame With Foot Bar Group
- 2 – Cover Group
- 3 – Extension Table Group
- 4 – Pedal Control Set

Images



[M7-5-101202 Support Drawing]

[Actual Image]