Hallbrookcomponents.com
Salbæk Technology Group
support@sal-tech.com
Skype: easy.packaging


Gripper Spring (H21-017) Installation Guide for Strapping Tensioner (for Cord Strap)

© Copyright 2020 Salbæk Technology Group

General Information

This document is a guide for Gripper Spring. Listed below are the machines which are compatible to the H21-017 Gripper Spring spare part:

- H-21
- H-22
- H-23
- H-25




© Copyright 2020 Salbæk Technology Group

Spare Parts Assembly


H21-017 Gripper Spring is part for the Tensioner for cord strap. The Gripper Spring is connected to the following spare parts:

4 – Needle Bearing, 1010 (H-25)
Bushing (H-22)
15 – Gripper
17 – Gripper Spring
18 – Gripper Plate
19 – Gripper Screw



The H21-017 Gripper Spring is installed between the H21-015/H25-015 (Gripper) and the H22-018/H25-018 (Gripper Plate) which is secured by H21-019 (Gripper Screw).

Images



[H21-017 Gripper Spring Drawing]

[Actual Image]

© Copyright 2020 Salbæk Technology Group