


# FMS, M4x25 (FMS0425) Installation Guide for Automatic Strapping Machine

## General Information

This document is a guide for Magnetic Switch. Listed below are the machines which are compatible to the FMS0425 FMS, M4x25 spare part:


- TP-702-59
- TP-702B
- TP-702BP
- TP-701C series
- TP-711N series



**Warning:** Before any maintenance or repairs on the machine, set the Main Power Switch to "O" (OFF). Wait about 5 minutes for cooling down the heater to avoid burns with this area.

## Spare Parts Assembly


FMS0425 FMS, M4x25 is a part for the Automatic Strapping Machine in the Strap Track Frame Ass'y.



**30 – FMS, M4x25**

**1 – Strap Track (For 5-6mm)**  
**Strap Track (For 9mm)**

FMS0425 FMS, M4x25 are installed within the Strap Track consists of 14~24 pcs.



1 – Strap Track (For 5-6mm)  
 Strap Track (For 9mm)


[Strap Track Frame Ass'y (For 5-6mm)]

[Strap Track Frame Ass'y (Stainless Steel Model)(For 5-6mm)]

[Strap Track Frame Ass'y (For 9mm)]

[Strap Track Frame Ass'y (Stainless Steel Model)(For 9mm)]

## Images



[T7-6-10690 Magnetic Switch Drawing]

[Actual Image]